


7 x y ~ x s | | s x |

이 제품은 실외에서만 사용하도록 제작된 상업시설 및 가정용 제품입니다.



전화: 1-888-690-9800(평일 오전 8시~오후 5시 태평양 표준시, 영어 및 스페인어 지원)

조립 시간: 60분(2명 기준) / 조립 시 필요한 도구: 렌치(동봉됨)

제품의 조립이나 설치 전 설명서 전체를 읽고 숙지하십시오. 이 제품은 장난감이나 공구로 사용할 수 없습니다. 제품을 작동, 조립, 제거, 분리할 때 어린이가 참여해서는 안 됩니다.

목차 / *Table of Contents*

관리 및 유지 보수	3
Care & Maintenance	7
보증	4
Warranty	9
의자 부품 목록	10
Chair Parts List	10
테이블 부품 목록	11
Table Parts List	11
테이블 조립	12
Table Assembly	12
열기 및 닫기 지침	14
Open and Close Instruction	14

관리 및 유지 보수

프레임

순한 비누로 손세탁하고 물로 깨끗이 행군 뒤 부드러운 천으로 말립니다.

표면이 손상될 수 있으므로 연마성 세척제를 사용하거나 너무 거칠게 문지르지 마십시오.

알루미늄 프레임을 오랫동안 사용하고 내구성을 유지하려면 겨울철에 가구를 커버로 덮거나 건조한 곳에 보관하십시오.

영하의 온도와 습기에 장시간 노출되면 프레임이 손상되어 구조 및 짜임에 문제가 발생할 수 있습니다.

커버

가구 커버는 혹독한 날씨와 자외선으로부터 제품을 보호하는 좋은 방법입니다.

그러나 커버로 가구를 덮기 전에 가구와 커버에 습기와 이물질이 없는지 꼭 확인해야 합니다.

또한 비온 뒤 또는 다습한 계절에는 습기가 쌓이지 않도록 가구 커버를 즉시 벗기십시오.

그렇지 않으면 표면 및 마감에 복구가 어려운 손상이 발생할 수 있습니다.

패브릭(천)

Phifer® 패브릭(천)은 정기적으로 세척해야 합니다.

먼지를 털어내고 순한 비누와 미지근한 물 용액으로 세척합니다.

얼룩이나 곰팡이가 심할 경우, 물 3.8L에 표백제 1컵(236ml)과 순한 비누액 1/4컵(59ml)을 섞은 용액으로 세척합니다.

비누 거품이 남아 있지 않도록 잘 행군 후 자연 건조합니다.

주의: 세탁기로 세탁하지 마십시오.

관리 및 유지 보수(계속)

테이블 상판

합성 목재 표면은 색이 바래는 것을 최소화하기 위해 UV안정제를 사용하여 만들었지만, 햇빛에 노출되면 모든 색상이 어느 정도 퇴색됩니다.

색이 바래거나 변하는 것을 최소화하려면 제품을 가구 커버와 같이 적절한 덮개로 씌우고, 사용하지 않을 때는 직사광선을 피해 보관하십시오.

합성목재 표면을 사포질하지 마십시오. 또한 표면에 페인트 또는 니스칠하지 않으며, 기타 코팅이나 화학약품을 바르지 마십시오.

천연 목재와 마찬가지로 합성 목재 표면은 매우 뜨거운 열기에 취약합니다. 바베큐 그릴, 조리 도구 또는 팬 등을 뜨거운 상태로 합성 목재 표면에 닿지 않도록 하십시오.

유리 소재(와인잔 등)를 장시간 탁상에 두면 빛 반사로 인해 손상될 수 있습니다.

물을 흘리거나 기타 이물질(예: 먼지, 기름, 오일 등)이 묻었을 때 방치하면 얼룩이 생기고 지워지지 않을 수 있으므로 바로 닦아내십시오.

기상 이변이나 부식을 일으키는 날씨(산성비, 유해 화학물질 또는 증기로 오염된 대기 등), 천재지변(화재, 홍수, 허리케인, 지진, 토네이도, 번개, 얼음 등),

환경 조건(대기 오염, 곰팡이, 녹 등)에서 사용하지 마십시오.

보증

2년 제한 보증*

이 제품은 구매일로부터 2년 동안 재료 및 제작상의 결함에 대한 제조업체 보증이 적용됩니다. 이 보증은 방치, 남용 또는 기상 관련 손상으로 인한 손상에는 적용되지 않습니다.


호주: 당사 상품에는 호주 소비자법에 따라 제외할 수 없는 보증이 제공됩니다. 귀하는 주요 고장에 대한 교체 또는 환불을 받을 자격이 있으며, 기타 합리적으로 예측 가능한 손실 또는 손상에 대한 보상을 받을 자격이 있습니다. 또한 상품이 허용 가능한 품질이 아니고 고장이 주요 고장에 해당하지 않는 경우 상품을 수리하거나 교체할 자격이 있습니다.

보증 공개에 관한 내용은 service@sunvilla.com 으로 이메일을 보내거나 <https://sunvilla.com> 에서 채팅을 통해 문의하십시오.

9 Piece Dining Set

ITM. / ART. 1807127

IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY
THIS ITEM IS INTENDED FOR OUTDOOR DOMESTIC USE ONLY.
NOT FOR COMMERCIAL USE.



Questions, problems, missing parts?

Before returning to your retailer, call our Customer Service Department at 1-888-690-9800 (8:00 am - 5:00 pm PT, Monday - Friday, English and Spanish) or email us at service@sunvilla.com.

Preparation

Before beginning to assemble this product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any parts are missing or damaged, do not attempt to assemble this product. Stop and call our customer service center.

Estimated Assembly Time: 20 minutes (2 persons). Tools Required for Assembly: Wrench (included).

Safety Information

Please read and understand this entire manual before attempting to assemble or install the product. It should not be used as a toy or tool. Children should not engage in the operation, assembly, removal, or disassembly of the product.

Care and Maintenance

Frame

Hand wash with mild soap and rinse thoroughly with water. Dry with a soft cloth. Do not use abrasive cleaners or scrub too rough as it may mar the surface. To ensure the longevity and durability of the aluminum frame, cover or store your furniture in a dry location during the winter months. Prolonged exposure to freezing temperatures and moisture can cause damage to the frame, affecting its structural integrity.

Covers

Furniture covers are a great way to protect your set from harsh elements of weather and UV light. However, it is important to ensure furniture and covers are free of moisture and debris before covering. It is also necessary to promptly uncover furniture after rain and during periods of high humidity to prevent moisture build up. Failure to do so can lead to permanent surface and finish damage.

Fabric

Phifer® fabric should be cleaned regularly.

Brush off any loose dirt and wash with a mild soap and lukewarm water solution.

For stubborn stains and mildew, wash with a solution of 236 ml (1 cup) of bleach and 59 ml (1/4 cup) of mild soap per 3.8 l (1 gallon) of water.

Rinse thoroughly to remove soap.

Allow fabric to air dry.

NOTE: Do not machine wash.

Care and Maintenance (cont.)

Table Top

Synthetic wood surfaces are made with UV-stabilizers to minimize fading, however, upon exposure to the sun, all colors will fade to some degree. To minimize possible fading or discoloration: keep product covered, utilize furniture covers where applicable, and minimize direct sunlight by storing product when not in use.

Do not sand or apply any paint, varnish or other coating or chemical to the synthetic wood surface.

Like a natural wood, the synthetic wood surface is susceptible to damage from extreme heat. Do not let heat from external sources such as a barbecue grill, cooking utensils, or pans come in contact with the synthetic wood surface. Leaving glass materials (such as a wine glass) on the tabletop for extended periods of time may cause damage due to light reflection.

Wipe up spills or other foreign substances (such as dirt, grease, oil, etc.) right away to avoid permanent staining.

Do not use under extreme weather or corrosive atmospheres (such as those contaminated by acid rain, harmful chemicals or vapors), or any act of God (such as fire, flooding, hurricane, earthquake, tornado, lightning, ice, etc.), environmental condition (such as air pollution, mold, mildew, etc.)

Warranty

2 YEAR LIMITED WARRANTY*

This product is covered under a manufacturer's 2 year warranty from the date of purchase against defects in materials and workmanship. This warranty does not cover damage due to neglect, abuse, or weather related damage.

AUSTRALIA: Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

For warranty disclosure, email us at: service@sunvilla.com or chat with us at <https://sunvilla.com>.


의자 부품 목록 / *Chair Parts List*

⚠ 경고 : 조립하는 동안 새 파티오 가구의 손상을 방지하려면 카펫 등 부드러운 표면이나 포장 상자를 깔고 그 위에서 작업하십시오.

⚠ **WARNING:** Perform all assembly steps on a flat, soft, non-abrasive surface to avoid scratching the finish.

부품 목록 PARTS LIST		설명 DESCRIPTION	수량 QTY
A		의자 프레임 Chair Frame	8

의자 사전 조립
Chair Pre-Assembled



중요: 설명서를 자세히 읽고 나중에 참고할 수 있도록 잘 보관하십시오.

IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY

테이블 부품 목록 / Table Parts List

⚠ 경고 : 조립하는 동안 새 파티오 가구의 손상을 방지하려면 카펫 등 부드러운 표면이나 포장 상자를 깔고 그 위에서 작업하십시오.

⚠ **WARNING:** Perform all assembly steps on a flat, soft, non-abrasive surface to avoid scratching the finish.




x2

예상 조립 시간: 20 분
조립 인원 : 2명(권장)

Estimated Assembly Time: 20 minutes
Recommended: 2 persons



손으로 조이기
Hand tighten



완전히 조이기
Fully tighten

부품 목록 PARTS LIST	설명 DESCRIPTION	수량 QTY
B	테이블 상판 Table Top	1
C	테이블 상판 2 Table Top 2	1
D	테이블 다리 Table Leg	1
E	테이블 다리 Table Leg	1
Z	가구 커버 Furniture Cover	1


부품 목록 PARTS LIST	설명 DESCRIPTION	수량 QTY
AA	M8x45 볼트 M8x45 Bolt	8
BB	M8x45 볼트 M8x45 Bolt	2
CC	와셔 플레이트 Washer Plate	4
DD	렌치 Wrench	1

중요: 설명서를 자세히 읽고 나중에 참고할 수 있도록 잘 보관하십시오.


IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY

테이블 조립 / *Table Assembly*

1






2



테이블 조립 / *Table Assembly*


3




열기 및 닫기 지침 / *Open and Close Instruction*

열려면 / *To Open :*


1




2




3




4



5




6




열기 및 닫기 지침 / *Open and Close Instruction*

닫기 / *To Close:*


1




2




3




4



5



6



SUNVILLA

Distributed by:
Costco Wholesale Corporation
P.O. Box 34535
Seattle, WA 98124-1535
USA
1-800-774-2678
www.costco.com

Costco Wholesale UK Ltd /
Costco Online UK Ltd
Hartspring Lane
Watford, Herts
WD25 8JS
United Kingdom
01923 213113
www.costco.co.uk

Costco Wholesale Japan Ltd.
2 Kakuchi, 2 Gaiku, Kaneda-Nishi
361 Urakura, Kisarazu shi
Chiba, 292-0007 Japan
0570-200-800
www.costco.co.jp

Costco Wholesale Sweden AB
Box 614
114 11 Stockholm
Sweden
www.costco.se

Costco Wholesale Canada Ltd.*
415 W. Hunt Club Road
Ottawa, Ontario
K2E 1C5, Canada
1-800-463-3783
www.costco.ca

* faisant affaire au Québec sous
le nom les Entrepôts Costco

Costco Wholesale Spain S.L.U.
Polígono Empresarial Los Gavilanes
C/ Agustín de Betancourt, 17
28906 Getafe (Madrid) España
NIF: B86509460
900 111 155
www.costco.es

Costco Wholesale Korea, Ltd.
40, Iljik-ro
Gwangmyeong-si
Gyeonggi-do, 14347, Korea
1899-9900
www.costco.co.kr

Importado por:
Importadora Primex S.A. de C.V.
Blvd. Magnocentro No. 4
San Fernando La Herradura
Huixquilucan, Estado de México
C.P. 52765
RFC: IPR-930907-S70
(55)-5246-5500
www.costco.com.mx

Costco Wholesale Iceland ehf.
Kauptún 3-7, 210 Gardabaer
Iceland
www.costco.is

Costco Wholesale New Zealand Limited
2 Gunton Drive
Westgate
Auckland 0814
New Zealand
www.costco.co.nz

Costco Wholesale Australia Pty Ltd
17-21 Parramatta Road
Lidcombe NSW 2141
Australia
www.costco.com.au

Costco France
1 avenue de Bréhat
91140 Villebon-sur-Yvette
France
01 80 45 01 10
www.costco.fr

Costco (China) Investment Co., Ltd.
Room 01 Mezzanine
No. 5178, Kang Xin Highway
Pudong New District
Shanghai
China 201315
+86-21-6257-7065

MADE IN CHINA
FABRIQUÉ EN CHINE
HECHO EN CHINA